September 8, 2003

Application Note:

Recommended Sequence for Powering RFM96 and TM32 Wireless Modems

To avoid potential malfunction of your RFM96 and TM32 Wireless Modems, follow the following sequence:

1. Connect antenna to antenna port
2. Apply power to unit
3. Wait 2 seconds
4. Apply data to serial port

If data appears at the serial port while the RFM96 or TM32 is initializing, this data may be interpreted by the radio modem firmware as a command, causing unpredictable results. Should this happen, remove data and power supply, and re-apply power following the sequence above.

Technical Support

If you need assistance please contact our Technical Assistance Center at 1.800.795.1001 or via email at support@paccrst.com.

PACIFIC CREST
CORPORATION
990 Richard Avenue, Suite 110
Santa Clara, CA. 95050
Toll Free: 800.795.1001 Phone: 408.653.2070 Fax: 408.748.9984
Email: support@paccrst.com Web: www.paccrst.com